

## Product Fiche

Supplier's name or trademark; **Focal Point Fires**

Model identifier; **Conventional Slimline Inset Radiant Heater**  
Gas Category/Pressure = **I<sub>2H</sub>(20)**

Energy Efficiency Class of the model; **F**

Direct heat output; **3.2 kW**

Indirect heat output; **N.A.**

Energy Efficiency Index; **48**

Useful Energy Efficiency at nominal heat output; **56.5%**

Useful Energy Efficiency at minimum load; **56.5%**

Specific precautions that shall be taken when the local space heater is assembled, installed or maintained;

This appliance must be installed, commissioned and maintained by a competent person. Prior to installation the competent person must ensure that the local distribution conditions (identification of the type of gas and pressure) and adjustment of the appliance are compatible.

The competent person must refer to and comply with the specific instructions listed in the Installation Manual before starting to install and commission the appliance.